

## **PURPOSE**

This document describes how to place the ACI/TUC Room Unit into the user options mode. The user options mode allows a user to change the configuration of the ACI/TUC Room Unit.

## **DEFINITIONS**

Options page mode

The mode of operation where the user can configure the TUC unit according to the application. Pages 100-109.

Options value mode

The mode of operation where the user selects one of the parameters for a given option page. Values 00-12.

## **PROCEDURE**

While the ACI/TUC Room Unit is displaying the current temperature, press and hold the DOWN and UP keys at the same time. The display will continue to show the current temperature while both keys are pressed. After approximately 30 seconds, the display will change to show 100 where the temperature is normally displayed. Once the 100 is displayed, stop pressing the DOWN and UP keys. The 100 on the display indicates successful entry into the options page mode.

If the DOWN key is pressed while the 100 is showing on the display, the ACI/TUC Room Unit shows the current firmware version on the display.

User accessible options occupy pages 101 through 109. Refer to the User Options Reference document for a complete description of the user option pages and option values.

To change an option page value, press the UP key until the desired option page is displayed. Then press the DOWN key to enter the option value mode. The current option value is now displayed. Press the UP key to change the option value. When the desired option value is displayed, press the DOWN key to store the selected option value and return to the option page mode. If you unintentionally go beyond the option value that you desire, continue to press the UP key until the correct option value appears. The UP key increments through the option value range of 00 to 12, and then the cycle repeats until you press the DOWN key. BE SURE TO PICK A VALID OPTION VALUE.

To return to normal operation from the option page mode, press the UP key until the display shows 1-- (one dash dash). Press the DOWN key to return the ACI/TUC Room Unit to normal operation.

If no key is pressed for approximately 10 seconds while in the option value mode, the ACI/TUC Room Unit will automatically return to the option page mode.

If no key is pressed for approximately 30 seconds while in the option page mode, the ACI/TUC Room Unit will automatically return to normal operation.